

mvXCell-8i

<u>Question</u>	<u>Date</u>
<u>Any demo software available on the mvXCell-8i? Any image processing benchmark?</u>	<u>14.10.2015</u>
<u>Is there any IP library available yet for the PowerXCell? Supported by MATRIX VISION?</u>	<u>14.10.2015</u>
<u>Is there mvIMPACT available for the PowerXCell?</u>	<u>14.10.2015</u>
<u>Do we have a working mvBlueFOX driver (USB camera) for mvXCell-8i?</u>	<u>14.10.2015</u>
<u>The boot process is interrupted and I cannot mount root fs.</u>	<u>14.10.2015</u>
<u>Files mentioned in the current getting started manual are not available on my SDK DVD.</u>	<u>14.10.2015</u>
<u>How is the mvXCell-8i card "seen" from the PC side? As a standard PCI Express device?</u>	<u>14.10.2015</u>
<u>Will you provide the software to communicate with mvXCell-8i under Windows OS?</u>	<u>14.10.2015</u>
<u>Is there anything else included in the MATRIX VISION SDK except the original IBM SDK 3.1?</u>	<u>14.10.2015</u>
<u>It is said that there are 3 configuration modes for the mvXCell-8i: preprocessor, accelerator, stand-alone/embedded but in another document (a getting started manual) why there are only 2 mode could be configured?</u>	<u>14.10.2015</u>

[Can I make the mvXCell-8i as the main processor but not the secondary one in preprocessor mode?](#) [14.10.2015](#)