

## Carte d'acquisition numérique PCI Express - mvHYPERION-CLb

Abandonné





- Carte d'acquisition numérique PCI Express® x1
- Différentes interfaces pour caméras "CameraLink"
- Contrôles "Trigger" et "Flash" embarqués

La carte d'acquisition mvHYPERION-CLb interface les caméras "CameraLink". Le format bus PCI Express® autorise une bande permanente de capture d'image jusqu'à 200 MB/s.

/\* \*/

- Sommaire
- Caractéristiques
- Comp. de cartes d'acquisition "PCI-E"
- Dom. d'application
- Téléchargem.

Product	mvHYPERION-CLb
PCI Express®	x1
Interfaces	1x BASE
Continuous data rate	Approx. 200 MB/s
Payload size	Up to 512 Bytes
Max. CL data clock	85 MHz
Digital In/Out	1x 2/1
Permissible ambient temperature	0 .. 45 °C
Permissible storage temperature	-20 .. 70 °C
Supported standards	 

- 1-channel multistandard CameraLink frame grabber for PCI Express® (x1 lane PCI-E)
- Trigger/sync input opto-isolated, 5..24 V
- Switchable input threshold of trigger and sync inputs between 2 V (TTL) and 12 V (PLC)
- PCI scatter gather DMA controller with PCI bus master feature and 0 Wait State Burst access
- Serial interface (LVDS)
- 1 MiniCL connector
- 1 connector for trigger + sync input, flash outputs and 12 V camera power
- Flash outputs opto-isolated, max. 30 V
- Retriggerable (asynchronous resettable)
- Intelligent creation of four

- Diverse data storage formats
- Supported CL spec.: 1.2
- camera control signals and strobe output per channel with independent video timing generators
- E2PROM
- Power over CameraLink (PoCL)

## Signal input

Family		mvDELTAe		mvSIGMA	mvHYPERION		
Product		(Cinch)	BNC	SQe	CLb	CLm	CLf
Inputs	CVBS	4	4	16	-	-	-
	YC	1 + 3 x	-	4	-	-	-
Parallel acquisition inputs	CVBS	4	4	16	-	-	-
	Gray/VBS	4	4	16	-	-	-
	RGB	-	-	-	-	-	-
	Digital	-	-	-	1	2	2
	Number	1	1	4	1	2	2
	RGB/ Multispectral	-	-	-	1	2	2
	Synchronous / asynchronous	-/-	-/-	yes/yes	-	yes/yes	-/-
A/D converter	(bit)	8	8	8	-	-	-
Standards	CCIR-601,	yes	yes	yes	-	-	-

Variable/ Slow Scan	-	-	-	-	-	-	-
PAL, NTSC, SECAM	yes	yes	yes	-	-	-	-
Low pass filter (analog) switchable	-	-	-	-	-	-	-
Restart / Reset	-	-	-	yes	yes	yes	yes
Sensor geometry	Area	ja	yes	yes	yes	yes	yes
Termination	Line Ohm / switchable	- 75 / no	- 75 / no	- 75 / no	yes 100 / no	yes 100 / no	yes 100 / no
Coupling / Level	AC	AC	AC	AC optional: yes	Digital differential / LVDS	Digital differential / LVDS	Digital differential / LVDS
Offset	-	-	-	-	-	-	-
Analog Gain	Manual / AGC	yes/yes	yes/yes	yes/yes	-	-	-
Plug connector	4 x Cinch + 1 x Mini-DIN4	4 x BNC	2x D-Sub 26	1 x MiniCL (1x BASE) 1x Binder 8pin	2 x MiniCL (2x BASE or 1x MED.) 2x Binder 8pin	2 x MiniCL (1x BASE or 1x MED. or 1x FULL) 2x Binder 8pin	

## Resolution

Family	mvDELTAe	mvSIGMA	mvHYPERION			
Product	(Cinch)	BNC	SQe	CLb	CLm	CLf
Digitalization	Pixels H x V (50 Hz)	768 x 576 (50 Hz)	768 x 576 (50 Hz)	-	-	-

Memory	Pixels H x V	0..768 x	0..768 x	0..768 x	64K x	64K x	64K x
		0..576 (50 Hz)	0..576 (50 Hz)	0..576 (50 Hz)	unlimited	unlimited	unlimited
		0..640 x	0..640 x	0..640 x			
		0..480 (60 Hz)	0..480 (60 Hz)	0..480 (60 Hz)			

Pixel clock

Family		mvDELTA		mvSIGMA	mvHYPERI		
Product		(Cinch)	BNC	SQe	CLb	CLm	CLf
Frequency	with 50 Hz	17.7 MHz	17.7 MHz	17.7 MHz	-	-	-
	with 60 Hz	14.3 MHz	14.3 MHz	14.3 MHz	-	-	-
	External	-	-	-	CL clock: 85 MHz	CL clock: 85 MHz	CL clock: 85 MHz

Digital ports

Family		mvDELTA		mvSIGMA	mvHYPERI		
Product		(Cinch)	BNC	SQe	CLb	CLm	CLf
Inputs	Ext. pixel clock	-	-	-	1	2	2
	HD, VD	-	-	-	1	2	2
	Trigger	-	-	4	1	2	2
				= 1 DigIn trigger			

			capable			
	Threshold pr	-	yes	no	no	no
	ogrammable					
	General	-	16	2	4	4
	inputs					
Outputs	TTL outputs	-	-	-	-	-
	Relay	-	-	-	-	-
	Highside	-	8 (12V)	-	-	-
	drivers		or ext. VDD			
			> 12V			
	General	-	8	1	2	2
	outputs					

FPGA

Family	mvDELTA		mvSIGMA	mvHYPERI		
	(Cinch)	BNC	SQe	ON		
Product				CLb	CLm	CLf
FPGA	-	-	-	yes	yes	yes

Bus

Family	mvDELTA		mvSIGMA	mvHYPERI		
	(Cinch)	BNC	SQe	ON		
Product	PCI Express	PCI Express	PCI Express	PCI Express	PCI Express	PCI Express
System	x1	x1	x1	x1	x4	x4
Transfer	up to 200	up to 200	up to 200	up to 200	up to 620	up to 620
	MB/s	MB/s	MB/s	MB/s	MB/s	MB/s

## Output processing

Family		mvDELTA	mvSIGMA	mvHYPERI ON			
Product		(Cinch)	BNC	SQe	CLb	CLm	CLf
Scaling		only down- scaling max. 1:16	only down- scaling max. 1:16	only down- scaling max. 1:16	-	-	-
Filtering		2,3,4 or 5 tap vertical filter	2,3,4 or 5 tap vertical filter	2,3,4 or 5 tap vertical filter	-	-	-
Pixel formats	RGB	8 / 15/ 16 / 24 / 32 bit	8 / 15/ 16 / 24 / 32 bit	8 / 15/ 16 / 24 / 32 bit	24 / 30 / 32 bit	24 / 30 / 32 bit	24 / 30 / 32 bit
	YC	16 bit planar / packed	16 bit planar / packed	16 bit planar / packed	-	-	-
	Gray	8 bit	8 bit	8 bit	8 / 10 / 12 / 14 / 16 bit	8 / 10 / 12 / 14 / 16 bit	8 / 10 / 12 / 14 / 16 bit

## Video output

Family		mvDELTA	mvSIGMA	mvHYPERI ON			
Product		(Cinch)	BNC	SQe	CLb	CLm	CLf
Signal	RGB	-	-	-	-	-	-
	CVBS, YC	-	-	-	-	-	-

## Sync output

Family	mvDELTA		mvSIGMA	mvHYPERI ON		
Product	(Cinch)	BNC	SQe	CLb	CLm	CLf
Signal	-	-	-	-	-	-

### Camera power supply

Family	mvDELTA		mvSIGMA	mvHYPERI ON		
Product	(Cinch)	BNC	SQe	CLb	CLm	CLf
Via PCI-E	12V	-	-	700mA	700mA	700mA
Via	12V	-	-	1.5A	2A	2A
additional power plug						

### Power requirements

Family	mvDELTA		mvSIGMA	mvHYPERI ON		
Product	(Cinch)	BNC	SQe	CLb	CLm	CLf
PCI-E	3.3V	0.15A	0.15A	0.15A	1A	1A
	12V	0.2A	0.2A	0.6A	0.05A	0.05A

### Dimensions



Family	mvDELTA		mvSIGMA	mvHYPERI ON		
Product Board	(Cinch)	BNC	SQe	CLb	CLm	CLf
Length (mm)	123	123	170	147	155	155
Width (mm)	95	95	111	95	111.5	111.5

#### Ambient conditions

Family	mvDELTA		mvSIGMA	mvHYPERI ON		
Product	(Cinch)	BNC	SQe	CLb	CLm	CLf
Permissible ambient temperature	0 .. 50 °C	0 .. 50 °C	0 .. 50 °C	0 .. 45 °C	0 .. 45 °C	0 .. 45 °C
Permissible storage temperature	-20 .. 70 °C	-20 .. 70 °C	-20 .. 70 °C	-20 .. 70 °C	-20 .. 70 °C	-20 .. 70 °C
Relative humidity	10-90%, non-condensing / non-10-90%, non-condensing / non-10-90%, non-condensing / non-10-90%, non-condensing / non-10-90%, non-condensing / non-10-90%, non-condensing					

#### Software

Family	mvDELTA		mvSIGMA	mvHYPERI ON		
Product Drivers	(Cinch)	BNC	SQe	CLb	CLm	CLf
	Windows® XP / Vista /	XP / Vista /	XP / Vista /	XP / Vista /	XP / Vista /	XP / Vista /

7 (32 bit / 64  
bit)

Linux®	yes	yes	yes	yes	yes	yes
Twain	yes	yes	yes	yes	yes	yes

All data refer to the current revision.

Area/Application	32R16	HD-SDI	CLx
<b>Industrial Image Processing</b>			
▶ 2D/3D measurement	■ ■ ■	■ ■ ■	■ ■ ■
▶ OCR, Pattern recognition	■ ■ ■	■ ■ ■	■ ■ ■
▶ control, robotics	■ ■ ■	■ ■ ■	■ ■ ■
▶ visualisation	■ ■ ■	■ ■ ■	■ ■ ■
▶ line camera applications	□ □ □	□ □ □	■ ■ ■
<b>Security</b>			
▶ object surveillance	■ ■ ■	■ ■ ■	■ ■ ■
▶ traffic surveillance	■ ■ ■	■ ■ ■	■ ■ ■
▶ compressed recording	■ ■ ■	■ ■ ■	■ ■ ■
▶ Video sensoric	■ ■ ■	■ ■ ■	■ ■ ■
<b>Microscopy/Diagnostic</b>			
▶ light microscopy	■ ■ ■	■ ■ ■	■ ■ ■
▶ laser scan systems	□ □ □	□ □ □	■ ■ ■
▶ electron microscopy	□ □ □	□ □ □	■ ■ ■
<b>Medicine</b>			
▶ visual dignostic	■ ■ ■	■ ■ ■	■ ■ ■
▶ laboratory systems	■ ■ ■	■ ■ ■	■ ■ ■
<b>Image Capture/Recording</b>			
▶ document line scanner	□ □ □	□ □ □	■ ■ ■
▶ high res area cameras	□ □ □	□ □ □	■ ■ ■
▶ broadcasting	■ ■ ■	■ ■ ■	□ □ □
<span style="color: blue;">■ ■ ■</span> optimum usage due to special features <span style="color: blue;">■ ■ ■</span> very suitable <span style="color: blue;">■ ■ ■</span> suitable			

mvHYPERION - application areas

Pilotes et applications pour Windows 7, 8.1 (mvIMPACT Acquire)


Depuis la version 2.10.1 de mvIMPACT Acquire, les "Merge Modules for mvIMPACT Acquire" sont disponibles en téléchargement séparé. Pour cette raison, les pilotes sont plus petits. Les "Merge Modules" ont besoin pour créer des séquences de configuration privés avec les pilotes "mvIMPACT Acquire". Plus de détails sont disponibles dans le [manuel mvIMPACT Acquire](#).

 [mvHYPERION x86 2.45.0.msi](#) | 97,580.0 kB

mvHYPERION 32 Bit Windows (7, 8.1, 10)

 [mvHYPERION x86\\_64 2.45.0.msi](#) | 116,536.0 kB

mvHYPERION-CLm/-CLf 64 Bit Windows (7, 8.1, 10)

 [mvIMPACT Acquire.history](#) | 924.2 kB

mvIMPACT Acquire History-Datei / mvIMPACT Acquire history file

## Versions antérieures des pilotes

Pour visualiser ou télécharger les pilotes, vous devez être [enregistré](#) ou [connecté](#).

Pilotes et applications pour Linux 2.6 - 3.x.x (mvIMPACT Acquire)

 [install mvHYPERION](#) | 38.4 kB

Linux Installer Skript für mvHYPERION devices / Linux installer script for mvHYPERION devices

 [mvHYPERION x86 ABI2 2.38.0.tgz](#) | 11,114.7 kB

mvHYPERION 32 Bit Linux

**Official support for Linux 32-bit x86/i386 systems has ended. If a newer version for this architecture is required please get in contact with the [support team](#).**

 [mvHYPERION x86\\_64 ABI2 2.45.0.tgz](#) | 13,729.4 kB

mvHYPERION 64 Bit Linux

 [mvIMPACT Acquire.history](#) | 924.2 kB

mvIMPACT Acquire History-Datei / mvIMPACT Acquire history file

## Versions antérieures des pilotes

Pour visualiser ou télécharger les pilotes, vous devez être [enregistré](#) ou [connecté](#).

Logiciels additionnels pour NeuroCheck, LabVIEW, DirectShow, VisionPro et Halcon

Since version 1.10.69, the **DirectShow®** driver is part of the mvIMPACT Acquire installation package.

Since version 1.10.85, an interface to **VisionPro®** (Cognex) will be installed automatically when installing an MSI based mvIMPACT Acquire driver package.

mvIMPACT Acquire bindings for **HALCON** are available on MVTec's website:


<http://www.halcon.de/download/>

 [LabVIEW acquire-x86-1.6.8](#) | 9,028.0 kB

32 Bit mvIMPACT Acquire Binding für LabVIEW ab Version 6.1 / 32 Bit mvIMPACT Acquire binding for LabVIEW 6.1 or greater

 [LabVIEW acquire-x86 64-1.6.8](#) | 10,980.0 kB

64 Bit mvIMPACT Acquire Binding für LabVIEW ab Version 6.1 / 64 Bit mvIMPACT Acquire binding for LabVIEW 6.1 or greater

 [LabVIEW acquire.history](#) | 7.2 kB

32 Bit LabView Binding History-Datei / 32 Bit LabView binding history file

Firmware

Le Firmware ne peut être utilisé qu'avec les cartes d'acquisition camera link!

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.85](#) | 862.7 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.85

Bug fix: Corrected sporadic horizontal image shift in Linescan Medium Mode.

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.84](#) | 865.3 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.84

Bug fix: Corrected Frame-Start trigger mode for area scan cameras.

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.83](#) | 856.5 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.83

Bug fix: Fixed overtriggering problem of the input in combination with a special linescan mode (FrameStart-Trigger=>FrameValid/RisingEdge, FrameStop-Trigger=>FrameValid/FallingEdge); Optimized automatic compensation of a phase error between Base, Medium, and Full channel.

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.82](#) | 868.8 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.82

Bug fix: Horizontal jitter in linescan trigger mode fixed; HRTC starting problem fixed

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.79](#) | 859.4 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.79

Bug fix: Line scan acquisition with TriggerControl-FrameStop fixed

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.78](#) | 849.0 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.78

New feature: ExpandLineValid feature implemented

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.77](#) | 847.1 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.77

Bug fix: "Raw Line Acquisition Mode" is working again

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.76](#) | 843.2 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.76

Bug fix: Removed sporadic horizontal offset (linescan mode)

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.74](#) | 865.3 kB



Firmware mvHYPERION-CLb/-CLm/-CLf v.74

Bug fix: Loss of first line after "Request" (linescan cameras)

 [Firmware mvHYPERION-CLb/-CLm/-CLf v.72](#) | 847.2 kB

Firmware mvHYPERION-CLb/-CLm/-CLf v.72

Documentations

 [mvHYPERION technical manual \(html\)](#)

mvHYPERION Technisches Handbuch / Technical Manual

 [mvHYPERION technical manual \(chm\)](#) | 2,722.9 kB

mvHYPERION Technisches Handbuch / Technical Manual

[Hinweis](#) / [Note](#)

 [mvHYPERION technical manual \(pdf\)](#) | 2,700.5 kB

mvHYPERION Technisches Handbuch / Technical Manual

 [mvIMPACT Acquire API C++](#) | 10,424.5 kB

mvIMPACT Acquire API C++ Handbuch / Manual


 [mvIMPACT Acquire API C](#) | 4,036.2 kB

mvIMPACT Acquire API C Handbuch / Manual

 [mvIMPACT Acquire API .NET](#) | 7,680.7 kB

mvIMPACT Acquire API .NET Handbuch / Manual

Brochures commerciales

 [mvHYPERION-Series e 2016-07 MR](#) | 4,661.5 kB

Datenblatt / Datasheet mvHYPERION

Modifications possibles sans préavis, date 10/2011